

MODE MACHINE • TECHNICAL RIDER - 2025



220V

PERSONAL
MIXER

* AUX 4
(IN EAR MONITOR 4)



GUITAR
PEDALBOARD



VOICE 2
(BACKING)

220V

AUX 3
(IN EAR MONITOR 3)



VOICE 1
(LEAD)

220V

AUX 2
(IN EAR MONITOR 2)



RACK - 1



RADIO-MIC 1

AUX 2

AUX 3

220V

RACK - 2



PERSONAL MIXER
KEYBOARDS + BACKINGTRACKS
+
VIDEO OUT (HDMI)



AUX 1



AUX 1
(IN EAR MONITOR 1)



→ LONG XLR CABLES FROM P.A. REQUIRED FOR DRUMMER PERSONAL MIXERS (AUX4) AND (AUX1,AUX2,AUX3,RADIO-MIC 1) , BEHIND THE KEYBOARDS STATION
→ LONG HDMI CABLE FOR VIDEO PROJECTION: SOURCE OUTPUT FROM (RACK - 2)

| MIXER CHAN. | INSTRUMENT | MIC / OUT | D.I. BOX | EXTERNAL FX REQUIRED |
|----------------|---------------------------|---|--------------|----------------------------|
| 1 | KICK (22"x18") | BETA52 / BETA91 / EV PL33 <i>(or similar)</i> <i>(REQUIRED)</i> | | COMP |
| 2 | SNARE 1 UP (14,5"x6,5") | E604 / E904 / EV PL35 <i>(or similar)</i> <i>(REQUIRED)</i> | | COMP |
| 3 | SNARE 1 DOWN (14,5"x6,5") | E604 / E904 / EV PL35 <i>(or similar)</i> <i>(REQUIRED)</i> | | COMP |
| 4 | SNARE 2 (10"x6,5") | E604 / E904 / EV PL35 <i>(or similar)</i> <i>(REQUIRED)</i> | | COMP |
| 5 | HI-HAT | KM184 / E614 <i>(or similar)</i> <i>(REQUIRED)</i> | | - |
| 6 | TOM 1 (12"x8") | E604 <i>(or similar)</i> <i>(REQUIRED)</i> | | GATE |
| 7 | TOM 2 (14"x14") | E604 <i>(or similar)</i> <i>(REQUIRED)</i> | | GATE |
| 8 | LOW TOM (16"x16") | E604 <i>(or similar)</i> <i>(REQUIRED)</i> | | GATE |
| 9 | ROTOTOM (6'+8') | E604 / E904 / PG48 <i>(or similar)</i> <i>(REQUIRED)</i> | | - |
| 10 | UNIDIRECTIONAL MIC - L | SM81 / E614 <i>(or similar)</i> <i>(REQUIRED)</i> | | - |
| 11 | UNIDIRECTIONAL MIC - R | SM81 / E614 <i>(or similar)</i> <i>(REQUIRED)</i> | | - |
| 12/13 | GUITAR L/R | PEDALBOARD STEREO OUT (XLR BAL) L/R | NOT REQUIRED | - |
| 14/15 | KEYBOARDS L/R | OUT (XLR BAL) L/R | NOT REQUIRED | - |
| 16/17 | STEREO TRACKS L/R | OUT (XLR BAL) L/R | NOT REQUIRED | - |
| 18 | VOICE 2 (BACKING VOICE) | SENNHEISER e835 <i>(PROVIDED)</i> | | COMP/REV/DEL |
| 19 | VOICE 1 (LEAD VOICE) | RADIO MIC SENNHEISER XSW2-835E <i>(PROVIDED)</i> | NOT REQUIRED | COMP/ REV/DEL |